



INSTRUCTIONS FOR USE

SPECIAL LAUNDERING INSTRUCTIONS FOR COATED COVERS

When laundering is required, the following instructions must be used.

- 1. Washing Instructions** - A slow speed machine must be used. The wash wheel is to be stopped for draining and refilling between each cycle.

Operation Cycle	Water Level	Time	Maximum Water Temperature	Supplies
1st Suds	High	5 min.	100° F	Neutral Soap & Alkali
2nd Suds	High	10 min.	100° F	Neutral Soap
3rd Rinse	High	3 min.	100° F	Water
4th Rinse	Low	3 min.	90° F	Sour to ph 5.0

NOTE: HARD TO CLEAN SPOTS - Use a soft sponge with a liquid household/vinyl cleaner.
Do not use harsh cleaners or solvents.

- 2. Dry Instructions** - Air dry. If machine drying is necessary tumble dry without heat.

- 3. IRONING** - Do not put covers through flatwork ironers.

CAUTION: Washing or drying in excess of the above recommendations will reduce service life and performance of the product.

NOTE: The above instructions are those recommended by the International Fabricare Institute for commercial washroom procedure.

* Save this document for future application, load rating and/or safety reference.

US/Can: 1.800.992.1776
Corporate Headquarters (US): 1.570.825.2741
For Inquiries Outside of the U.S. and Canada, Visit www.metro.com/contactus

www.metro.com



L01-023 Rev.A
03/2016