

**A**

**ROTATE POSTS**  
so SLOTS face in  
as shown - same  
direction as MAT  
WIRES

**HANDLE STOP - OPEN**      **CLOSED**

**IMPORTANT!**  
Handle Stops  
and Mat Wires  
**MUST** look like  
this from top  
(looking down).

**B**

1. Install the 2  
handle stops  
over two posts  
at diagonally  
opposite  
corners as  
shown.

2. Attach top shelf to the  
posts, using 4 sets of split  
sleeves on the top grooves  
of the posts. Be sure mat  
wires on shelf are running  
the same direction as on  
the bottom shelf.

3. Seat the shelf collars and attach the "C"  
Rings as shown below.

**C**

1. Assemble the qwikSLOT Clips as shown at bottom center. Each clip fits into 2 slots on the posts. Attach one set of 4 Clips to the posts at the 10th and 11th visible slots down from the top shelf.

2. Attach the second set of 4 clips to the posts at the 9th and 10th slots up from the bottom shelf.

quikSLOT CLIPS

**D**

1. Hang the two slide assemblies on the qwikSLOT Clips as shown, and engage the locks on the clips as shown at bottom right.

2. Attach grounding cable to bottom shelf mat wires as shown.

GROUNDING CLIP

**PCB  
PALLET  
TRUCK  
ASSEMBLY**

**NOTE:**  
Pallets sold  
separately.

**"C" Rings**

**quikSLOT Clip**

**LOCK**

**quikSLOT Clip**

**LOCK**

**LOCK**